

ICTP 2012

Mesh Networking Lab

Part 1

Sebastian Buettrich sebastian@less.dk

last updated: Feb 2012

Lab

- Flashing a wireless device
- OpenWRT based mesh nodes – on mixed hardware (Linksys WRT54G, Ubiquiti Pico, NanoStation & Bullet)
- Routing protocol: OLSR

- Optional: Trying B.A.T.M.A.N., 802.11s
- Optional: Running olsrd on a PC/laptop
- Optional: Running batmand on a PC/laptop
- Optional: Android phone mesh / servalproject.org

Flashing

- **Flashing** a wireless device means **replacing its firmware with an alternative firmware**
- Methods for flashing:
 - 1) Through web GUI – often works for devices in default state.
 - 2) via tftp – when the web GUI does not work
 - 3) if all that fails – via serial ports, soldering etc
 - 4) if nothing works: you have a *brick* :)

Choosing firmware

- Find out exactly what hardware model and hardware revision you have
- Find the right firmware accordingly and verify that it will run

Examples of firmware:

OpenWRT – list of supported hardware:

<http://wiki.openwrt.org/toh/start>

We will use a variety of Ubiquiti devices, so check

<http://wiki.openwrt.org/toh/start#ubiquiti>

- Freifunk http://wiki.freifunk.net/Freifunk_Firmware_%28English%29

Classical Freifunk firmware was targetted at Linksys WRT54G and similar devices

Newest Freifunk software comes as packages to be installed under OpenWRT. Kamikaze/Builder allows for creation of packages for all hardware platforms supported by OpenWRT Kamikaze

OpenWRT versions for Ubiquiti

- Look at

<http://wiki.openwrt.org/toh/start#ubiquiti>

to find

Ubiquiti Nanostation2, Bullet2 -

<http://downloads.openwrt.org/kamikaze/8.09.2/atheros/openwrt-atheros-ubnt2-squashfs.bin>

Ubiquiti Picostation2 -

<http://downloads.openwrt.org/backfire/10.03.1/atheros/openwrt-atheros-ubnt2-pico2-squashfs.bin>

Flashing a wireless device via Web interface

- Have firmware ready on your computer
- Find out the device's default IP
- Set your own computers IP accordingly (same network, different IP)
- Connect to the device's original web interface (see: Access Point configuration) and find the "Firmware Update" button, or similar, if there is any
- Use this to upload and install new firmware
- **NOW: REMEMBER TO WAIT!
DO NOT PRESS CONTINUE WHEN IT SHOWS!!! DONT!!!
WAIT UNTIL THE LEDS STOP BLINKING!
TYPICALLY 4-6 MINUTES!**
- **MAKE SURE YOU HAVE STABLE POWER WHILE DOING THIS!
IF YOU DO NOT TRUST GRID POWER, USE A BATTERY!**

Flashing a wireless device via tftp

- Connect the device to your computer via ethernet cable.
- Set your computer to be 192.168.1.x, but not 192.168.1.20 (which is the Ubiquiti default IP)
- Power down the device.
- Power it back up, while at the same time holding the reset button, for about 10 seconds.
- By now, the second LED should be flashing green, and the device be pingable on 192.168.1.20
- The device is now waiting for a tftp transfer. It might look like this:

```
sb@sb-laptop:~$ tftp
tftp> connect 192.168.1.20
tftp> binary
tftp> put <firmware-filename>.bin
Sent 2989541 bytes in 13.2 seconds
```

- **Remember to be patient – Dont interrupt it.**
- **MAKE SURE YOU HAVE STABLE POWER WHILE DOING THIS!**
IF YOU DO NOT TRUST GRID POWER, USE A BATTERY!

Working with OpenWRT

- OpenWRT comes with the LuCi webGUI
 - Go to webgui, default is `http://192.168.1.1`
 - Set password!
-
- Alternative: instead of using the GUI, use ssh & command line

If not, set up a root password in the device:

```
telnet 192.168.1.1
```

```
passwd
```

- ssh into the device using the root password you've just entered

Adding software packages to OpenWRT

- Note you will need to have your device connected to the internet, so you may need a switch, and good idea how to connect :)

Hint: you could set the device to receive a DHCP lease, or set a static IP – while you do this, you might wanna connect to the device wirelessly.

Once you are done, you can use the newly configured ethernet connection to connect to it.

But this also means, we need to start coordinating within our group:

192.168.4.2-50
is free for static addresses

192.168.4.49	= Sebastian
192.168.4.48	=
192.168.4.47	=
192.168.4.46	=
192.168.4.45	=
192.168.4.44	=
192.168.4.43	=

Adding software packages to OpenWRT

- Update packages
- Note you will need to have your device connected to the internet, so you may need a switch, and good idea how to connect :)

Hint: you could set the device to receive a DHCP lease, or set a static IP – while you do this, you might wanna connect to the device wirelessly.

Once you are done, you can use the newly configured ethernet connection to connect to it.

- Add packages you need, e.g.

for OLSR:

```
opkg install luci-app-olsr
```

Adding software packages to OpenWRT

- Update packages
- Note you will need to have your device connected to the internet, so you may need a switch, and good idea how to connect :)

Hint: you could set the device to receive a DHCP lease, or set a static IP – while you do this, you might wanna connect to the device wirelessly.

Once you are done, you can use the newly configured ethernet connection to connect to it.

- Add packages you need, e.g.

for OLSR:

```
opkg install luci-app-olsr
```

Configuring OLSR in OpenWRT

- When olsr is installed, in the web gui, go to Services, and configure OLSR

The screenshot shows the OpenWRT web GUI interface. The browser address bar displays the URL: `192.168.4.49/cgi-bin/luci/stok=dbf61694ff0320cc9c88214cb8ae8a8d/admin/services/`. The page title is "OpenWrt | OpenWrt Backfire 10.03.1 | Load: 0.03 0.08 0.16". The navigation menu includes "Status", "System", "Services", "Network", and "Logout". The "Services" tab is active, and the "OLSR" sub-tab is selected. The "OLSR Daemon" configuration page is displayed, featuring a description of the daemon and a "General settings" section with four tabs: "General Settings", "Link Quality Settings", "SmartGW", and "Advanced Settings". The "General Settings" tab is active, showing the following configuration options:

Field	Value	Description
Internet protocol	IPv4	IP-version to use. If 6and4 is selected then one olsrd instance is started for each protocol.
FIB metric	flat	FIBMetric controls the metric value of the host-routes OLSRd sets. "flat" means that the metric value is always 2. This is the preferred value because it helps the linux kernel routing to clean up older routes. "correct" uses the hopcount as the metric value. "approx" use the hopcount as the metric value too, but does only update the hopcount if the nexthop changes too. Default is "flat".
Port	698	The port OLSR uses. This should usually stay at the IANA assigned port 698. It can have a value between 1 and 65535.
Main IP	0.0.0.0	Sets the main IP (originator ip) of the router. This IP will NEVER change during the uptime of olsrd. Default is 0.0.0.0, which triggers usage of the IP of the first interface.

http://wiki.ubnt.com/OLSR_on_OpenWrt
<http://wiki.openwrt.org/inbox/mesh.olsr>

•

Configuring OLSR in OpenWRT

- When olsr is installed,
in the web gui, go to **Services**, and configure OLSR

IP settings: need fixed IP ... again we need to agree!

192.168.4.40 Sebastian

SSID = LabMesh

channel 1

BSSID = 00:CA:FF:EE:BA:BE

Remember to enable OLSR on the right interface

Configuring OLSR in OpenWRT

- When olsr is installed, in the web gui, go to Services, and configure OLSR

The screenshot shows the OpenWRT web interface. The browser address bar displays the URL: `192.168.4.49/cgi-bin/luci/stok=dbf61694ff0320cc9c88214cb8ae8a8d/admin/services/`. The page title is "OpenWrt | OpenWrt Backfire 10.03.1 | Load: 0.03 0.08 0.16". The navigation menu includes "Status", "System", "Services", "Network", and "Logout". The "Services" tab is active, and the "OLSR" sub-tab is selected. The "OLSR Daemon" configuration page is displayed, featuring a description: "The OLSR daemon is an implementation of the Optimized Link State Routing protocol. As such it allows mesh routing for any network equipment. It runs on any wifi card that supports ad-hoc mode and of course on any ethernet device. Visit olsrd.org for help and documentation." Below the description are four tabs: "General Settings", "Link Quality Settings", "SmartGW", and "Advanced Settings". The "General Settings" tab is active, showing the following configuration fields:

Internet protocol	IPv4 <small>IP-version to use. If 6and4 is selected then one olsrd instance is started for each protocol.</small>
FIB metric	flat <small>FIBMetric controls the metric value of the host-routes OLSRd sets. "flat" means that the metric value is always 2. This is the preferred value because it helps the linux kernel routing to clean up older routes. "correct" uses the hopcount as the metric value. "approx" use the hopcount as the metric value too, but does only update the hopcount if the nexthop changes too. Default is "flat".</small>
Port	698 <small>The port OLSR uses. This should usually stay at the IANA assigned port 698. It can have a value between 1 and 65535.</small>
Main IP	0.0.0.0 <small>Sets the main IP (originator ip) of the router. This IP will NEVER change during the uptime of olsrd. Default is 0.0.0.0, which triggers usage of the IP of the first interface.</small>

http://wiki.ubnt.com/OLSR_on_OpenWrt
<http://wiki.openwrt.org/inbox/mesh.olsr>

•

Old slides for reference:

Freifunk, debricking,
olsrd on linux laptop,
etc

Lab: Configuring a Freifunk Mesh

Mesh planning

- **Planning is about people! Consider the social dynamics, ownership, support, ...**
- **Map / Site Survey**
- **Select network topology**
- **Channel allocation (mesh, backbone, local hotspots)**
- **IP address allocation**
- **Draw the network diagram**

Lab: Freifunk Firmware on Linksys WRT54G

Debricking a WRT54G

- power down the WRT54GL
- Example of a tftp transmission:
on a linux command line, do
[root@samsarix /]# ifconfig eth1 192.168.1.99 up
[root@samsarix /]# tftp -v -m binary 192.168.1.1
mode set to octet
Connected to 192.168.1.1 (192.168.1.1), port 69
tftp> put openwrt-g-freifunk-1.6.25-en.bin
<NOW POWER UP THE WRT54GL! and if you are lucky... it will say>
putting openwrt-g-freifunk-1.6.25-en.bin to 192.168.1.1:openwrt-g-freifunk-1.6.25-en.bin [octet]
Sent 1303552 bytes in 7.9 seconds [1326539 bit/s]
tftp>
- If debricking via tftp fails, you will have to open the device and do some pin magic – read more here:

http://www.notsecure.us/debrick_wrt54g_without_void_warrenty.html

[http://www.ranvik.net/prosjekter-](http://www.ranvik.net/prosjekter-privat/jtag_for_wrt54g_og_wrt54gs/HairyDairyMaid_WRT54G_v22.pdf)

[privat/jtag_for_wrt54g_og_wrt54gs/HairyDairyMaid_WRT54G_v22.pdf](http://www.ranvik.net/prosjekter-privat/jtag_for_wrt54g_og_wrt54gs/HairyDairyMaid_WRT54G_v22.pdf)

<http://www.freewebs.com/wrt54grevival/wrt54grevial.htm.html>

Lab: Running olsrd / batmand on a laptop

- Olsr demons are available for Linux, Mac OS X, BSD, Windows: <http://www.olsr.org/?q=download>
- Also: Ubuntu plugins, .debs, Nokia, iPhone
- Linux: install via the normal make routine
Do this in the lib directories too to activate libs!
- Windows: GUI OLSR-Switch might be out of date!
- Biggest obstacle in all of this: card and driver issues (ad-hoc mode often badly buggy)

Lab: Running olsrd / batmand on a laptop olsrd on Linux

- Download sources, build

```
(in olsr dir)
```

```
# make
```

```
# make install
```

```
# cd lib
```

```
# make install
```

```
(...)
```

Lab: Running olsrd / batmand on a laptop olsrd on Linux

- Prepare settings and start the demon
- example session:

```
# killall NetworkManager
# killall NetworkManagerDispatcher
# killall olsrd
# ifconfig ath0 172.31.1.19 netmask
255.255.255.0
# iwconfig ath0 essid roadshow-mesh mode ad-hoc
channel 1
# olsrd -i ath0 -d 5
# netstat -nr
```